



# ROCK-IT<sup>®</sup>

## Automatic pool ball launcher



### WARNING

- This device contains a rechargeable lithium Ion battery and electronic components.
- Do not expose this device to liquid or high temperatures greater than 40°C
- Use only the provided battery charger.
- Please dispose of this device properly. Recycle electronic waste at collection points provided in your local region.
- Small parts may come off. Keep out of reach of children.

### CAUTION

- **WATCH OUT FOR MOVING BALLS!** Avoid or prevent contact with the device to maintain ball placement consistency and prevent damage to equipment.
- **Be careful when placing balls onto the launch ramp.** Do not drop balls onto the launch ramp as this could cause damage to the launch ramp.
  - It is recommended to remove all balls from the launch ramp before detaching the dispensing mechanism to avoid dropping any balls onto the launch ramp. Balls can be physically pushed through the dispensing mechanism if necessary.
- **Store at a consistent temperature.** Approximately 21°C and 40%-50% humidity.

Automatically set up and organize balls, while practicing pocket billiard shots and strokes:

- Adjustable timer can be set to practice shooting a ball every 4 to 21 seconds.
- Lithium Ion rechargeable battery lasts up to 24 hours per charge.
- Launch ramp has a maximum capacity of eleven balls, and can be positioned and repositioned to perform almost any shot desired.

## OPERATING INSTRUCTIONS

1. Attach the dispensing mechanism to the launch ramp.
2. Carefully load balls onto the launch ramp.
3. Press the button to initiate the shot sequence.
4. Turn the knob to adjust the rate balls are released onto the pool table surface.
5. Move the launch ramp to adjust the position of the ball.

## TIPS

- Avoid ANY movement of the launch ramp to maintain ball placement consistency.
- The last 2 balls in the sequence will generally roll a little further than the other balls. To achieve the most precise ball placement, reload the launch ramp when there are 2 or more balls remaining on the launch ramp.

